

Data Sheet

For part # FF-CRMP-MOST
Crimp size: MOST ferrule



Process: 4 indent Crimping
Product Name: POF Crimping tools
Service Crimping Tools, Indent, PEW 8.71 frame

Description:

This hand tool is for crimping the male and female MOST contacts to the POF cable Ø 2.3 mm was designed and manufactured pursuant to state-of-the-art technical requirements that were set up by the MOST cooperation for the automotive industry to have a way to repair and install the male and female MOST contacts to the POF cable. This is a very simple instruction to receive very repetitive results:

- Strip and cut the POF cable (see MOST Finishing Tool Part# FF-MOST-2)
- Insert the ferrule into the tools ferrule accommodation, then move the holding tab
- Insert the cable into the ferrule and Close the tool *(crimp)
- * (The bottom portion of the tool has a polished stop that is setup at the factory that controls the proper crimp length)
- Open the crimp tool, release the contact lock and remove the cable with the crimped contact

Frame Model No.: PEW 8.71
Finish Type: burnished
Handles: plastic coated two-component

Length: 180 mm
Weight: 425 g

Others: for POF contacts of the MOST System

For service call: FiberFin technical department
630-553-6924 ext 114 8-5pm CST
Email: technical questions or comments to: Sevice@fiberfin.com

Step-by-Step Instructions



Step 1: Insert ferrule



Step 2: Apply clamp



Step 3: Insert finished cable



Step 4: Close the handle and crimp

You're done!



Back side of tool



MOST Ferrules male and female